

To switch on and off mdrrc with a button.
connect a momentary push button between x5-4 and ground
no pc connection nessasary.

